

**Rajiv Gandhi University of Knowledge
Technologies Basar**

LABORATORY MANUAL

SOIL MECHANICS ENGINEERING LAB

DEPARTMENT OF CIVIL ENGINEERING

RGUKT BASAR

TELANGANA. -504107

Contents

S.No	Name of the experiment	Page no
1	Soil moisture content	3
2	Soil Specific Gravity	4
3	Grain size analysis- Mechanical method	5
4	Grain size analysis- Hydrometer analysis	7
5	Atterberg limits determination	10
6	Determination of shrinkage of soils	12
7	In-situ density of soils – Sand jar cone method	14
8	Compaction test	17
9	Coefficient of permeability – Falling head method	19
10	Consolidation test	21
11	Direct shear test	26
12	Unconfined Compression Test(UC)	28
13	Soil Triaxial Compression	30
14	Vane Shear Test	33

Experiment No. 1: Soil Moisture Content

Aim

Determination of moisture content (water content) of soil.

Apparatus

Drying oven, Non-corrodible metal cans with lids, Balance (0.001 g accuracy for fine-grained soils), Spatula, Gloves.

Procedure

1. Record the number of can and lid. Clean, dry, and record their weight.
2. Using a spatula, place about 15-30 g of moist soil in the can. Secure the lid, weigh and record.
3. Maintain the temperature of the oven at $110 \pm 5^\circ\text{C}$. Open the lid, and place the can in the oven. Leave it overnight.
4. After drying, remove the can carefully from the oven using gloves or tongs. Allow it to cool to room temperature.
5. Weigh the dry soil in the can along with lid.
6. For each soil, perform at least 3 sets of the test.

Observations and Calculations

Tabulate observations and results of the tests as shown.

Test No.	1	2	3	4
Can No.				
Mass of can with lid, W_1 (g)				
Mass of can with lid + wet soil, W_2 (g)				
Mass of can with lid + dry soil, W_3 (g)				
Mass of water, $W_w = W_2 - W_3$ (g)				
Mass of dry soil, $W_s = W_3 - W_1$ (g)				
Moisture content, $w = \frac{W_w}{W_s} \times 100$ (%)				

Result

Average moisture content, w (%) =

Experiment No. 2: Soil Specific Gravity

Aim

Determination of the specific gravity of soil particles finer than 2 mm.

Apparatus

Small pycnometer (density bottle of 50 ml capacity), Balance (accuracy 0.001 g), Funnel, Spoon, Distilled water, Heater, Thermometer.

Procedure

1. Wash, dry and weigh the pycnometer.
2. Place about 10 g of dry soil sample in the pycnometer. Weigh the bottle with the soil.
3. Add sufficient distilled water to cover the soil, and heat the bottle to remove all entrapped air
4. Remove the bottle from the heater and fill the bottle with water up to the calibration mark.
5. Clean the exterior surface of the bottle pycnometer with dry cloth, and weigh the bottle with contents.
6. Empty the bottle and clean it. Fill it with distilled water up to the mark and record its weight.
7. Conduct the test for 3 times.

Observations and Calculations

Test temperature (°C) =

Test No.	1	2	3
Pycnometer / Density bottle No.			
Mass of pycnometer, W1 (g)			
Mass of pycnometer + dry soil, W2 (g)			
Mass of pycnometer + soil + water, W3 (g)			
Mass of pycnometer + water, W4 (g)			
Specific gravity of soil, $G_s = \frac{(W_2 - W_1)}{(W_2 - W_1) - (W_3 - W_4)}$			

Result

Average specific gravity of soil grains =

Experiment No.3: Grain size analysis – Mechanical Method

Aim

Determination of quantitative size distribution of particles of soil down to fine-grained fraction.

Apparatus

Set of sieves (4.75 mm, 2.8 mm, 2 mm, 1 mm, 600 micron, 425 micron, 300 micron, 150 micron, 75 micron), Balance (0.1 g accuracy), Drying oven, Rubber pestle, Cleaning brush, Mechanical shaker.

Procedure

1. Take a suitable quantity of oven-dried soil. The mass of soil sample required for each test depends on the maximum size of material.
2. Clean the sieves to be used, and record the weight of each sieve and the bottom pan.
3. Arrange the sieves to have the largest mesh size at the top of the stack. Pour carefully the soil sample into the top sieve and place the lid over it.
4. Place the sieve stack on the mechanical shaker, screw down the lid, and vibrate the soil sample for 10 minutes.
5. Remove the stack and re-weigh each sieve and the bottom pan with the soil sample fraction retained on it.

Observations and Calculations

Initial mass of soil sample taken for analysis (kg) =

Sieve size (mm)	Mass of sieve (g)	Mass of sieve + soil (g)	Soil retained (g)	Percent retained (%)	Cumulative percent retained (%)	Percent finer (%)
4.75 mm						
2.8 mm						
2 mm						
1 mm						
600 micron						
425 micron						
300 micron						
150 micron						
75 micron						
Pan						

1. Obtain the mass of soil retained on each sieve. The sum of the retained masses should be approximately equal to the initial mass of the soil sample.

2. Calculate the percent retained on each sieve by dividing the mass retained on the sieve with the total initial mass of the soil.
3. Calculate the cumulative percent retained by adding percent retained on each sieve as a cumulative procedure.
4. Calculate the percent finer by subtracting the cumulative percent retained from 100 percent.
5. Make a grain size distribution curve by plotting sieve size on log scale and percent finer on ordinary scale.
6. Read off the sizes corresponding to 60%, 30% and 10% finer. Calculate the uniformity coefficient (C_u) and the curvature coefficient (C_c) for the soil.

Result

Coefficient of uniformity (C_u) of the soil =

Coefficient of curvature (C_c) of the soil =

Experiment No. 4: Grain size analysis – Hydrometer analysis

Aim

Determination of the quantitative size distribution of particles of soil fraction finer than 75 micron.

Apparatus

Hydrometer (calibrated at 27°C, range of 0.995 to 1.030 g/cc), Two 1000 ml graduated glass cylinders, Dispersing agent solution containing sodium hexametaphosphate, Evaporating dish, Thermometer, Stop-watch, Mechanical stirrer.

Procedure

1. Take 50 g of dry soil in an evaporating dish, add 100 ml of dispersing agent, and prepare a suspension.
2. Transfer the suspension into the cup of a mechanical stirrer, add more distilled water, and operate the stirrer for three minutes.
3. Wash the soil slurry into a cylinder, and add distilled water to bring up the level to the 1000 ml mark.
4. Cover the open end of the cylinder with a stopper and hold it securely with the palm of the hand. Then turn the cylinder upside down and back upright repeatedly for one minute.
5. Place the cylinder down and remove the stopper. Insert a hydrometer and start a stop-watch simultaneously. To minimize bobbing of the hydrometer, it should be released close to the reading depth. This requires some amount of rehearsal and practice.
6. Take hydrometer readings on the upper rim of the meniscus formed by the suspension and the hydrometer stem after time intervals of periods of 0.5, 1, 2 and 4 minutes, .
7. After the 4 minutes reading, remove the hydrometer slowly, and float it in a second cylinder containing 100 ml dispersing agent and distilled water up to 1000 ml mark.
8. Take further readings after elapsed time periods of 8, 15 and 30 minutes, and also after 1, 2, 4, 8 and 24 hours. Insert the hydrometer only just before the reading and withdraw immediately after the reading.
9. Observe and keep recording the temperature of the soil suspension.
10. Shake the solution in the second cylinder thoroughly. Insert the hydrometer and note the meniscus correction, which is the reading difference between the top of the meniscus and the level of the solution in the cylinder when observed along the hydrometer stem.
11. The composite correction is the difference between the top meniscus reading and value of 1.000 corresponding to the usual hydrometer calibration temperature of 27°C. This may be positive or negative.

12. Calibrate the hydrometer to establish a relation between any reading and its corresponding effective depth, and obtain a calibration plot. The effective depth is the distance from the surface of the soil suspension to the level at which the density of the suspension is being measured.

Observations and Calculations

Mass of dry soil taken (passing 75 micron), W (g) =

Specific gravity of soil grains, $G_s =$

Meniscus correction, $C_m =$

Elapsed time, t (min)	Actual hydrometer reading, R_h	Temperature, T ($^{\circ}C$)	Comp-site correction, C	Corrected hydrometer reading, $R_{c1} = R_h + C_m$	Effective depth, h (cm)	$\sqrt{\frac{h}{t}}$	Viscosity, η (g sec/cm ²)	Factor M	Particle size, D (mm)	$R_{c2} = R_h \pm C$	Factor N	% Finer w.r.t mass taken, F	% Finer w.r.t total mass

Calculation of Particle Size

1. Enter hydrometer readings. Add meniscus correction and obtain corrected hydrometer readings R_{c1} .

2. From calibration plot, obtain effective depth h corresponding to R_{c1} .

3. Calculate value of $\sqrt{\frac{h}{t}}$

4. Obtain viscosity value η corresponding to temperature T. Calculate factor, M

$$M = \sqrt{\frac{18\eta}{\gamma_s - \gamma_w}}$$

5. Calculate particle size D by multiplying M and $\sqrt{\frac{h}{t}}$

Calculation of Percentage Finer

1. Add the composite correction C to the hydrometer reading to get another corrected hydrometer reading R_{c2} .

2. Calculate factor, N

$$N = \frac{G_s}{(G_s - 1)} \times \frac{100}{W}$$

3. Calculate percentage finer F by multiplying R_{c2} and N.

4. Calculate percentage finer with respect to total mass of soil taken for sieve analysis and hydrometer analysis.

Total percent finer = F x fine-grained percent in the total soil mass.

Present results by plotting particle size vs. percent finer on a semi-logarithmic sheet.

IIIT Basar

Experiment No. 5: Atterberg limits determination -Liquid Limit, Plastic Limit, Shrinkage Limit

Aim

Determination of the liquid and plastic limits of a soil.

Apparatus

Liquid limit device and grooving tools, Metal rod of 3 mm diameter, Apparatus for moisture content determination, Porcelain evaporating dish, Spatula, Wash bottle filled with distilled water, Measuring cylinder, Glass plate.

Procedure for Liquid Limit

1. Take about 150 gm of dry soil passing 425 micron sieve, and mix it with distilled water in a porcelain dish to form a uniform paste.
2. Place a portion of the paste in the cup of liquid limit device with a spatula, press the soil down to remove air pockets, spread it to a maximum depth of 10 mm, and form an approximately horizontal surface.
3. By holding a grooving tool perpendicular to the cup, carefully cut through the sample from back to front, and form a clean straight groove in the centre by dividing into two halves.
4. Turn the crank handle of the device at a steady rate of two revolutions per second. Continue turning until the two halves of the groove is closed along a distance of 13 mm. Record the number of blows to reach this condition.
5. Take about 15 gm of the soil from the joined portion of the groove to a moisture can for determining water content.
6. Transfer the remaining soil from the cup into the porcelain dish. Clean and dry the cup and the grooving tool.
7. Repeat steps 2 to 6, and obtain at least four sets of readings evenly spaced out in the range of 10 to 40 blows.

Procedure for Plastic Limit

1. Use the remaining soil from the porcelain dish.
2. Take about 10 gm of the soil mass in the hand, form a ball, and roll it between the palm or the fingers and the glass plate using complete motion of the hand forward and reverse.
3. Apply only sufficient pressure to make a soil thread, and continue rolling until a thread of 3 mm diameter is formed. Comparison can be made with the metal rod.
4. If the diameter becomes less than 3 mm without cracking, turn the soil into a ball again, and re-roll. Repeat this remoulding and rolling process until the thread starts just crumbling at a diameter of 3 mm.

5. Gather the pieces of crumbled thread and place them in a moisture can for determining water content.

6. Repeat steps 2 to 5 at least two more times with fresh samples of 10 gm each

Observations and Calculations

Determination of Liquid Limit

Test No.	1	2	3	4	5
No. of blows					
Can No.					
Mass of can (g)					
Mass of can + wet soil, (g)					
Mass of can + dry soil, (g)					
Mass of water (g)					
Mass of dry soil (g)					
Water content (%)					

Calculate the water contents, and plot the number of blows (on log scale) versus the water content (on ordinary scale). Draw the best-fit straight line through the points.

Liquid Limit = Water content corresponding to 25 blows

Determination of Plastic Limit

Test No.	1	2	3	4	5
Can No.					
Mass of can (g)					
Mass of can + wet soil, (g)					
Mass of can + dry soil, (g)					
Mass of water (g)					
Mass of dry soil (g)					
Water content (%)					

Plastic Limit = Average of the computed water contents

Experiment No. 6: Determination of Shrinkage Limit Of Soils

AIM

To determine shrinkage limit of the soil

APPARATUS

Shrinkage dish, Porcelain evaporated dish, Mercury, Balance

PROCEDURE

1. About 30 gms of soil passing through 425 micron sieve is taken with distilled water.
2. The shrinkage dish is coated with a thin layer of Vaseline .The soil sample is placed in the dish by giving gentle taps. The top surface is surfaced with a straight edge.
3. The shrinkage dish with wet soil is weighed. The dish is dried first in air and then in oven.
4. The shrinkage dish is weighed with dry soil. After cleaning the shrinkage dish its empty weight is taken.
5. An empty porcelain dish which will be useful for weighing mercury is weighed.
6. The shrinkage dish is kept inside a large porcelain dish it is filled with mercury and the excess is removed by pressing the plain glass plate firmly over the top of the dish. The contents of the shrinkage dish are transferred to the mercury weighing dish and weighed.
7. The glass cup is kept in a large dish, filled it with over flowing mercury, the excess is removed by pressing the glass plate with three prongs firmly over the top of the cup.
8. It is placed in another large dish. The dry soil is placed on the surface of the mercury and submerge it under the mercury by pressing with the glass plate with prongs.
9. The mercury displaced by the dry soil pat is transferred to the mercury weighing dish and weighed.

OBSERVATION AND CALCULATIONS

TABLE

Sl.No	Description	Trial 1	Trial 2	Trial 3
1	Weight of dish + wet soil pat in gms			
2	Weight of dish + dry soil pat in gms			
3	Weight of water present (2-3)			
4	Weight of shrinkage dish , empty (gms)			

5	Weight of dry soil pat $W_s = (2 - 4)$			
6	Initial water content $(W1) = (4) / (6) \times 100$			
7	Weight of weighing dish + Mercury			
8	Weight of weighing dish empty			
9	Weight of mercury (7 - 8)			
10	Volume of wet soil pat			
11	Weight of weighing dish + displaced mercury			
12	Weight of mercury displaced			
13	Volume of dry soil pat			
14	Shrinkage limit			
15	Shrinkage ratio			
16	Volumetric shrinkage			
17	Linear shrinkage			

RESULT

1. Shrinkage limit =

2. Shrinkage ratio =

3. Volumetric shrinkage =

IIIT Basar

Experiment No. 7: In-situ density of soils – Sand jar cone method

Aim

Determination of the in-situ density of soils by core cutter method or sand replacement method.

Core Cutter Method

Apparatus

Cylindrical core cutter, Dolley, Rammer, Balance (1 g accuracy), Spade, Straight edge knife, Sample extruder, Apparatus for moisture content determination.

Procedure

1. Measure the internal dimensions of the core cutter and weigh it.
2. Clean and level the site surface where the field density is to be determined.
3. Place the dolley on the cutter and press both into the soil using the rammer until only about 15 mm of the dolley protrudes above the surrounding soil surface.
4. Remove the soil around the cutter with the spade, lift up the cutter, and trim carefully the top and bottom surfaces of the soil sample.
5. Clean the outside surface of the cutter and weigh it with the soil.
6. Remove the soil core from the cutter and take three representative samples in moisture cans for water content determination.

Sand Replacement Method

For hard and gravelly soils, the core-cutter method is not suitable. In its place, sand replacement method can be used, and it involves making a hole in the ground, weighing the excavated soil and determining the volume of the hole.

Apparatus

Sand pouring cylinder, Calibrating cylinder, Clean and dry sand, Metal tray with a central circular hole, Balance (1 g accuracy), Glass plate, Trowel, Scraper tool, Apparatus for moisture content determination.

Procedure

1. An inverted cone forms the base of the sand pouring cylinder, and a shutter at the cone tip controls the release of sand through a uniform free fall.
2. First determine the bulk density of the sand to be used in the field. For this, measure the internal dimensions of the calibrating cylinder so as to obtain its volume. Fill the pouring cylinder with sand

and weigh. Place it concentrically on top of the calibrating cylinder, and allow sand to run out and fill both the calibrating cylinder and the inverted conical portion.

3. To obtain only the mass of sand filling up the conical portion, lift the pouring cylinder and then weigh with remaining sand. Place it on a glass plate, and allow sand to run out. Weigh again the pouring cylinder with left over sand.
4. Calculate the mass of sand that fills up the calibrating cylinder, and from its known volume, work out the bulk density of the sand for the allowed free fall.
5. Clean and level the site surface, and place the square tray with a central hole. Excavate a hole of diameter equal to that of the tray hole and depth equal to about 15 cm. Collect the excavated soil in the tray, weigh and then take representative samples for water content determination.
6. Fill the pouring cylinder with the same sand, place it concentrically over the hole, open the shutter and allow sand to fill up the hole.
7. When there is no further movement of sand, close the shutter, remove the cylinder and weigh it with the remaining sand.

Core Cutter Method - Observations and Calculations

Internal diameter of core cutter (cm) =

Height of cutter (cm) =

Volume of cutter, V (cm³) =

Field Test No.	1	2	3	4
Mass of core cutter (g), W ₁				
Mass of cutter + soil (g), W ₂				
Mass of moist soil (g), (W ₂ - W ₁)				
Average water content, w (%)				
Field bulk density (g/cm ³), $\gamma_t = \frac{W_2 - W_1}{V}$				
Field dry density (g/cm ³), $\gamma_d = \frac{\gamma_t}{1 + w}$				

In-situ dry density = Average of the computed values

Sand Replacement Method - Observations and Calculations

Volume of calibrating cylinder (cm³), V₁ =

Mass of sand for filling the calibrating cylinder and cone (g), W₁ =

Mass of sand for filling only the cone (g), W₂ =

Mass of sand in the calibrating cylinder (g), $W_3 = W_1 - W_2$

Bulk density of sand (g/cm^3), $\gamma_{\text{sand}} = \frac{W_3}{V_1}$

Field Test No.	1	2	3	4
Mass of pouring cylinder + sand before pouring in hole (g), W_4				
Mass of pouring cylinder + sand after pouring in hole (g), W_5				
Mass of sand used in the hole (g), $W_6 = W_4 - W_5 - W_2$				
Volume of excavated hole (cm^3), $V_h = \frac{W_6}{\gamma_{\text{sand}}}$				
Mass of excavated soil (g), W_7				
Average water content, w (%)				
Field bulk density (g/cm^3), $\gamma_t = \frac{W_7}{V_h}$				
Field dry density (g/cm^3), $\gamma_d = \frac{\gamma_t}{1 + w}$				

In-situ dry density = Average of the computed values

Experiment No. 8: Compaction test

Aim

Determination of the dry density - moisture content relationship of a soil.

Apparatus

Cylindrical moulds and accessories, Rammer, Sample extruder, Balance (1 g accuracy), 4.75 mm IS sieve, Mixing tray, Trowel, Graduated cylinder, Straight edge knife, Apparatus for moisture content determination.

Procedure

1. Obtain a sufficient quantity of air-dried soil and pulverize it. Take about 3 kg of soil passing through 4.75 mm sieve in a mixing tray.
2. Weigh the mould with base plate and apply grease lightly on the interior surfaces. Fit the collar and place the mould on a solid base.
3. Add water to the soil to bring its moisture content to about 8% and then mix it thoroughly using the trowel until the soil gets a uniform colour.
4. For light compaction, compact the moist soil in three equal layers using a rammer of mass 2.6 kg and having free fall of 31 cm. Distribute the blows evenly, and apply 25 blows in each layer. Ensure that the last compacted layer extends above the collar joint. Alternatively for heavy compaction, compact the soil with 25 blows per layer, in five equal layers with a rammer of mass 4.9 kg and 45 cm free fall.
5. Rotate the collar so as to remove it, trim off the compacted soil flush with the top of the mould, and weigh the mould with soil and base plate.
6. Extrude the soil from the mould and collect soil samples from the top, middle and bottom parts for water content determination. Place the soil back in the tray, add 2% more water based on the original soil mass, and re-mix as in step 3. Repeat steps 4 and 5 until a peak value of compacted soil mass is reached followed by a few samples of lesser compacted soil masses.

Observations and Calculations

Diameter of mould, d (cm) =

Wt. of rammer (kg) =

Height of mould, h (cm) =

No. of layers =

Volume of mould, V (cm³) =

No. of blows/layer =

Mass of mould, W (g) =

Test No.	1	2	3	4	5	6
Mass of mould + compacted soil (g)						
Mass of compacted soil, W_t (g)						
Bulk density, $\gamma_t = \frac{W_t}{V}$						
Average water content, w (%)						
Dry density, $\gamma_d = \frac{\gamma_t}{1+w}$ (g/cc)						
Dry density at 100% saturation (g/cc)						

1. Calculate the bulk density of each compacted soil specimen.
2. Calculate the average moisture content of the compacted specimen and then its dry density.

$$\gamma_d = \frac{G_s \cdot \gamma_w}{1 + \frac{w \cdot G_s}{S}}$$

3. Plot the dry densities obtained as ordinates against the corresponding moisture contents as abscissa, draw a smooth compaction curve passing through them, and obtain the values of maximum dry density (MDD) and optimum moisture content (OMC).
4. On the same graph, plot a curve corresponding to 100% saturation.

where, S = degree of saturation, G_s = specific gravity of solids, and γ_w = unit weight of water.

Results

MDD (g/cc) =

OMC (%) =

IIT Basar

Experiment No. 9: Coefficient of permeability – Falling head method

Aim

Determination of the coefficient of permeability of a soil using constant head apparatus or variable head apparatus.

Apparatus

Permeameter mould and accessories, Circular filter papers, Compaction device, Constant head reservoir, Graduated glass standpipes along with support frame and clamps, Measuring flask, Stopwatch.

Procedure for Constant Head Test

1. Take 2.5 kg of dry soil and prepare it to obtain desired water content.
2. Apply little grease on to the interior sides of the permeameter mould.
3. Keep a solid metal plate in the groove of the compaction base plate. Assemble the base plate, mould and collar. Compact the soil into the mould.
4. Remove the collar and base plate, and replace the solid metal plate with a porous stone covered with filter paper.
5. Trim off excess soil from the top of the mould and place another porous stone with filter paper on it. Attach the top cap of the permeameter.
6. Connect a constant head reservoir to the bottom outlet of the mould. Open the air vent of the top cap, and allow water to flow in and upwards till the soil gets saturated.
7. Disconnect the reservoir from the bottom outlet and connect it to the top inlet. Close the air vent and allow water to establish a steady flow.
8. Collect the water in a measuring flask for a convenient time interval. For similar time intervals, measure the flow quantity for at least three times.
9. After the test, measure the temperature of the water.

Observations and Calculations

Constant Head Flow

Diameter of sample, D (cm) =

Length of sample, L (cm) =

Area of sample, A (cm²) =

Volume of sample, V (cm³) =

Initial mass of sample, W (g) =

initial water content, w (%) =

Moulding density (g/cm³) =

Head loss, h (cm) =

Hydraulic gradient, $i = h / L =$
 Temperature of water, $T (^{\circ}\text{C}) =$

Test No.	1	2	3
Time interval, t (sec)			
Quantity of flow, Q (cm^3)			
Coefficient of permeability (cm/sec), $k = \frac{Q}{Ait}$			

Correction factor due to temperature, $C_T = \frac{\eta_T}{\eta_{27}}$ where η is viscosity of water.
 Permeability at $27^{\circ}\text{C} =$ Average of the computed values $\times C_T$

Procedure for Variable Head Test

1. Follow the same steps 1 to 6 as for the constant head test.
2. Disconnect the reservoir from the bottom outlet and connect a selected standpipe to the top inlet.
3. Fill the standpipe with water, close the air vent and allow water to flow.
4. Open the bottom outlet and record the time interval required for the water surface in the standpipe to fall between two levels as measured from the centre of the outlet.
5. Measure time intervals for similar drops in head at least three times after re-filling the standpipe.
6. At the end of the test, measure the temperature of the water.

Observations and Calculations

Variable Head Flow

Diameter of standpipe, d (cm) =
 Cross-sectional area of standpipe, a (cm^2) =

Test No.	1	2	3
Initial head, h_1 (cm)			
Final head, h_2 (cm)			
Time interval in seconds, ($t_2 - t_1$)			
Coefficient of permeability (cm/sec), $k = \frac{2.3La \log_{10} \left(\frac{h_1}{h_2} \right)}{A(t_2 - t_1)}$			

Permeability at $27^{\circ}\text{C} =$ Average of the computed values $\times C_T$

Experiment No. 10: Consolidation test

Aim

Determination of one-dimensional consolidation parameters of an undisturbed cohesive soil sample.

Apparatus

Consolidation cell, Ring, Porous stones, Loading frame and dial gauge, Water reservoir, Trimming tools, Balance, Filter paper, Stop-watch, Apparatus for moisture content determination.

Procedure

1. Clean the consolidation ring and measure its inside diameter, height and weight.
2. Press the ring gently into the undisturbed soil sample until soil projects above the top of the ring, lift it up with extreme care, and trim the soil surfaces flush both at the top and bottom of the ring. Remove any excess soil sticking outside, and weigh the specimen with ring. Take samples from the remaining soil mass for determination of initial water content.
3. Place soaked porous stones on the top and bottom surfaces of the soil specimen with filter paper discs in between. Press lightly to ensure that the stones adhere to the specimen.
4. Assemble the specimen carefully into the consolidation cell, mount the cell on the loading frame, and set the dial gauge. Connect the system to a water reservoir, and allow the water to flow into till the specimen is completely covered and saturated.
5. Adjust and record initial dial gauge reading. Apply normal load to give a pressure intensity of 0.1 kg/cm^2 on the soil specimen.
6. Note the dial gauge readings at elapsed times of 0, 0.25, 1, 2.25, 4, 6.25, 9, 12.25, 16, 20.25, 25, 36, 49, 64, 81, 100, 169, 256, 361, etc. up to 24 hrs.
7. Increase the normal load to double of the previous pressure intensity as in step 5, and take dial gauge readings at the same elapsed time intervals as in step 6. Use a loading sequence of 0.1, 0.2, 0.4, 0.8, 1.6, 3.2 kg/cm^2 , etc.
8. On completion of the final loading stage, decrease the load to $\frac{1}{4}$ of the last load, allow it to remain for 24 hours, and then note the dial gauge reading. Reduce further the load in steps of one-fourth the previous load and repeat the observations. If data for repeated loading is required, increase the load intensity and take dial readings.
9. After recording the final time and dial reading, siphon water out of the consolidation cell, release the load, quickly disassemble the cell, remove the ring, and blot the specimen surfaces dry with paper
10. Weigh the specimen with ring, and place in the oven for determination of final water content.

Observations and Calculations

Diameter of ring (mm) =

Area of ring (mm^2), A =

Height of ring (mm), H =

Mass of ring (g) =

Specific gravity of solids, $G_s =$

Before Test

Mass of ring + wet soil (g) =

Initial moisture content (%), $w_i =$

Initial height of specimen (mm), $H_i =$

$$H_s = \frac{W_s}{G_s \cdot A \cdot \gamma_w} \text{ After Test}$$

Mass of ring + wet soil (g) =

Mass of dry soil (g), $W_s =$

Final moisture content (%), $w_f =$

Height of solids (mm),

Total change in height (mm) =

Final height of specimen (mm), $H_f =$

$$e = \frac{H}{H_s} - 1 \text{ After any stage}$$

Height of specimen (mm), $H =$

Void ratio at increased pressure,

$$S = \frac{w \cdot G_s}{e} \text{ Degree of saturation (\%),}$$

Void ratio at initial pressure, $e_0 =$

IIIT Basar

Table 1: Time - settlement data for different pressure intensities

Date									
Start time									
Pressure intensity (kg/cm ²)		p ₁		p ₂		p ₃		p ₄	
Elapsed time (t) (min)	\sqrt{t}	Dial gauge readings and compression							
		Reading	Comp. (mm)	Reading	Comp. (mm)	Reading	Comp. (mm)	Reading	Comp. (mm)
0	0								
0.25	0.5								
1	1								
2.25	1.5								
4	2								
6.25	2.5								
9	3								
12.25	3.5								
16	4								
20.25	4.5								
25	5								
36	6								
49	7								
64	8								
81	9								
100	10								
225	15								
400	20								
900	30								
3600	60								
14400	120								
57600	240								
230400	480								
921600	960								
2073600	1440								

Table 2: Calculation of e , a_v and m_v

Applied pressure p (kg/cm ²)	Final dial readings (mm)	Change in height of sample ΔH (mm)	Height of sample $H = H_i - \Delta H$ (mm)	Void ratio $e = \frac{H}{H_s} - 1$	Δe	Coefficient of compressibility $a_v = -\frac{\Delta e}{\Delta p}$ (cm ² /kg)	$1 + e_0$	Coefficient of volume compressibility $m_v = \frac{a_v}{1 + e_0}$ (cm ² /kg)
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)
0								
0.1								
0.2								
0.4								
0.8								
1.6								
3.2								
6.4								

1. Calculate the void ratio at the end of each pressure increment, and plot void ratio vs. pressure variation on simple graph paper. Determine coefficient of compressibility and coefficient of volume compressibility for each increment.
2. Plot void ratio vs. log pressure, and obtain compression index and preconsolidation stress (maximum past pressure).
3. For each pressure intensity, plot compression vs. \sqrt{t} , and determine t_{90} by square root of time fitting method. Also construct a semilog plot of compression vs. time on log scale, and determine t_{50} by logarithm of time fitting method.

$$c_v = \frac{0.848}{t_{90}} \left(\frac{H}{2} \right)^2$$

4. Calculate values of coefficient of consolidation (c_v) for each pressure intensity applied to the specimen.

From square root of time fitting method,

From logarithm of time fitting method

$$c_v = \frac{0.197}{t_{50}} \left(\frac{H}{2} \right)^2$$

Experiment No. 11: Direct shear test

Aim

Determination of shear strength parameters of a silty or sandy soil at known density and moisture content.

Apparatus

Shear box with clamping screws, Box container, Porous stones, Grid plates (serrated and perforated), Tamper, Balance, Loading frame, Proving ring, Deformation dial gauges, Apparatus for moisture content determination.

Procedure

1. Measure shear box dimensions, set up the box by fixing its upper part to the lower part with clamping screws, and then place a porous stone at the base.
2. For undrained tests, place a serrated grid plate on the porous stone with the serrations at right angle to the direction of shear. For drained tests, use a perforated grid over the porous stone.
3. Weigh an initial amount of soil in a pan. Place the soil into the shear box in three layers and for each layer apply a controlled amount of tamping with a tamper. Place the upper grid plate, porous stone and loading pad in sequence on the soil specimen. Weigh the pan again and compute the mass of soil used.
4. Place the box inside its container and mount it on the loading frame. Bring the upper half of the box in contact with the horizontal proving ring assembly. Fill the container with water if soil is to be saturated.
5. Complete the assembly, remove the clamping screws from the box, and initialize the horizontal displacement gauge, vertical displacement gauge and proving ring gauge to zero.
6. Set the vertical normal stress to a predetermined value. For drained tests, allow the soil to consolidate fully under this normal load. Avoid this step for undrained tests.
7. Start the motor with a selected speed and apply shear load at a constant rate of strain. Continue taking readings of the gauges until the horizontal shear load peaks and then falls, or the horizontal displacement reaches 20% of the specimen length.
8. Determine the moisture content of the specimen after the test. Repeat the test on identical specimens under different normal stress values.

Observations and Calculations

Size of box (mm) =
Area of box (cm²) =
Volume of box (cm³) =

Least count of displacement dial gauge (mm/div.) =

Proving ring constant (kg/div.) =

Soil Specimen No. =

Mass of soil (kg) =

Density of soil (kg/cm^3) =

Normal stress applied (kg/cm^2) =

Horizontal dial reading (Div)	Horizontal displacement (mm)	Shear strain	Load dial reading (Div)	Horizontal shear force (kg)	Shear stress (kg/cm^2)

1. Calculate the density of the soil specimen from the mass of soil and the volume of the shear box.
2. Convert the dial readings to the appropriate displacement and load units by multiplying with respective least counts.
3. Calculate shear strains by dividing horizontal displacements with the specimen length, and obtain shear stresses by dividing horizontal shear forces with the shear area.
4. Plot the shear stress versus horizontal displacement. Read the maximum value of shear stress if failure has occurred, otherwise read the shear stress at 20% shear strain.
5. Plot the maximum shear stress versus the corresponding normal stress for each test, draw the Mohr-Coulomb failure envelope, and determine the cohesion and the angle of shearing resistance of the soil.

Results

Cohesion (kg/cm^2) =

Angle of shearing resistance ($^\circ$) =

Experiment No.12: Unconfined Compression Test(UC)

Aim

Determination of unconfined compressive strength of a clayey soil either in undisturbed or remoulded condition.

Apparatus

Compression machine, Proving ring, Deformation dial gauge, Timer, Sampling tube, Specimen extruder, Split mould, Specimen trimming tools, Vernier calipers, Balance, Apparatus for moisture content determination.

Procedure

1. Prepare the test specimen, which may be either undisturbed, remoulded or compacted. Undisturbed specimens can be carved from a large soil block, or obtained through a sampling tube from which the specimen can be extruded to a split mould using a sample extruder.
2. Trim the two ends of the soil specimen, remove it from the mould, and measure the length, diameter and weight.
3. Place the specimen on the bottom plate of the compression machine, and adjust the upper plate to make contact with the specimen. Initialize the vertical displacement gauge and proving ring gauge to zero. Select an axial strain rate between 0.5% to 2.0% per minute and apply compression load.
4. Record the load and displacement readings at every 20 to 50 divisions of displacement gauge, or at every 15 seconds.
5. Compress the specimen till the load peaks and then falls, or till the vertical deformation reaches 20% of the specimen length.
6. Remove the specimen from the machine, and take soil samples for water content determination.

Observations and Calculations

Least count of deformation dial gauge (mm/div.) =

Proving ring constant (kg/div.) =

Soil Specimen No. =

Type of specimen: Undisturbed/Remoulded

Initial length of specimen, L_0 (mm) =

Initial diameter of specimen, D_0 (mm) =

Initial area of specimen, A_0 (cm^2) =

Elapsed	Vertical deformation (ΔL)	Vertical	Corrected	Compressive load	Compressive
---------	-------------------------------------	----------	-----------	------------------	-------------

time (min)			strain $\xi = \frac{\Delta L}{L_0}$	area $A = \frac{A_0}{1 - \xi}$ (cm ²)			stress (kg/cm ²)
(1)	(div.)	(mm)	(4)	(5)	(div.)	(kg)	(8) = (7)/(6)

1. Convert the dial readings to the appropriate vertical deformation and compressive load units by multiplying with respective least counts.
2. Calculate vertical strain, corrected cross-sectional area and then compressive stress.
3. Plot stress-strain curve, and show unconfined compressive strength q_u as the peak stress or the stress at 20% strain.
4. Draw a Mohr circle using q_u , and determine undrained shear strength $s_u =$ undrained cohesion $c_u = q_u/2$
5. Compute the water content, w (%).

Results

Water content (%) = _____
 Unconfined compressive strength (kg/cm²) = _____
 Undrained shear strength (kg/cm²) = _____

Experiment No. 13: Soil Triaxial Compression

Aim

Determination of shear strength parameters of soils under triaxial loading conditions.

Apparatus

Triaxial cell, Compression machine, Cell pressure application system, Pore pressure measuring device, Volume change measuring device, Proving ring, Deformation dial gauge, Split mould, Trimming knife, Rubber membrane, Membrane stretcher, Rubber 'O' rings, Balance, Apparatus for moisture content determination.

Procedure

1. Prepare a test specimen of necessary diameter and length, and measure its weight. Place a rubber membrane around the specimen using the membrane stretcher.
2. De-air the outlet line at the pedestal of the triaxial base, place on its top a saturated porous stone with a filter paper disc, and then position the soil specimen with the membrane stretcher around it. Put a loading cap on the specimen top, and seal the membrane on to the bottom pedestal and the top cap with 'O' rings.
3. Assemble the triaxial cell with the loading ram initially clear of the top cap. Fill the cell with water, raise the water pressure to the desired value, and maintain the pressure constant. Raise the platform of the compression machine to bring the ram in contact with the seat on the top cap.
4. Set both the proving ring dial gauge and the deformation dial gauge to zero, select an axial strain rate, and verify that the cell pressure remains constant.
5. For undrained shearing of saturated samples, either close the outlet valve at the base of the cell or connect it to a pore pressure transducer. For drained shearing of saturated samples, connect the outlet to a burette for volume change measurements.
6. Apply axial compression load and take readings of the proving ring at intervals of 0.20 mm vertical deformation till the peak load has been passed, or till the strain reaches 20% of the specimen length. Record also burette or pore pressure readings, as applicable.
7. Remove the axial load, drain the water from the cell, remove the specimen, make a sketch of the failure pattern, and take soil samples for water content determination.
8. Repeat the test on identical soil specimens under different cell pressures.

Observations and Calculations

Least count of deformation dial gauge (mm/div.) =

Proving ring constant (kg/div.) =

Soil Specimen No. =

Confining cell pressure, σ_3 (kg/cm²) =

Initial diameter of specimen, D_0 (mm) =

Initial length of specimen, L_0 (mm) =

Initial area of specimen, A_0 (cm²) =

Initial volume of specimen, V_0 (cm³) =

Deformation dial reading (ΔL)		Vertical strain $\xi = \frac{\Delta L}{L_0}$	Burette reading (DV) (cm ³)	Pore pressure change (Du) (kg/cm ²)	Proving ring dial reading		Corrected area for undrained test $A = \frac{A_0}{1 - \xi}$ (cm ²)	Corrected area for drained test $A = \frac{V_0 - \Delta V}{L_0 - \Delta L}$ (cm ²)	Deviatoric stress ($\sigma_1 - \sigma_3$) (kg/cm ²)
(div.)	(mm)				(div.)	(kg)			
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10) = (7)/A

1. Convert the dial readings to the appropriate vertical deformation and compressive load units by multiplying with respective least counts.

2. Calculate vertical strain, and compute corrected area as $A = \frac{A_0}{1 - \xi}$ for undrained tests, and as $A = \frac{V_0 - \Delta V}{L_0 - \Delta L}$ for drained tests. Determine the deviatoric stress.

3. Plot stress-strain curve, and obtain the peak stress or the stress at 20% strain.
4. Draw Mohr circles using effective principal stresses at failure for all tested specimens. From the Mohr-Coulomb failure envelope, determine the cohesion and the angle of shearing resistance of the soil.
5. Compute the water content, w (%).

Results

Water content (%) =

Cohesion (kg/cm^2) =

Angle of shearing resistance ($^\circ$) =

Experiment No. 14: Vane Shear Test

Aim:

To find shear strength of a given soil specimen.

Apparatus:

1. Vane shear apparatus.
2. Specimen.
3. Specimen container.
4. Callipers.

PROCEDURE:

1. Prepare two or three specimens of the soil sample of dimensions of at least 37.5 mm diameter and 75 mm length in specimen. (L/D ratio 2 or 3).
2. Mount the specimen container with the specimen on the base of the vane shear apparatus. If the specimen container is closed at one end, it should be provided with a hole of about 1 mm diameter at the bottom.
3. Gently lower the shear vanes into the specimen to their full length without disturbing the soil specimen. The top of the vanes should be at least 10 mm below the top of the specimen. Note the readings of the angle of twist.
4. Rotate the vanes at a uniform rate say 0.1°/s by suitable operating the torque application handle until the specimen fails.
5. Note the final reading of the angle of twist.
6. Find the value of blade height in cm.
7. Find the value of blade width in cm.

CALCULATIONS:

$$\text{Shear strength, } S = \frac{T}{\pi(D^2H/2 + D^3)}$$

Where S = shear strength of soil in kg/cm²

T = torque in cm kg

D = overall diameter of vane in cm

T = spring constant / 180° x difference in degrees.

OBSERVATIONS:

Soil description:

S.No	Initial Reading (Deg)	Final Reading (Deg.)	Difference (Deg.)	T=Spring Constant/180x Difference Kg-cm	$G = 1 / \pi(D^3 H / 2 + D^3 / 6)$	S=Tx G Kg/cm ²	Average 'S' Kg/cm ²	Spring Constant Kg-cm

GENERAL REMARKS:

This test is useful when the soil is soft and its water content is nearer to liquid limit.